

HOW TO INSTALL YOUR BLIND

You will need: Power drill & bit
 Phillips screwdriver
 Pencil

Unpack your blind & check all the parts on the list. Do not unroll the blind.

If your blind is to be mounted inside the window, it will be top mounted as in Fig. 1 & Fig .2

If your blind is to be mounted on the architrave it will be face mounted as in Fig.3



Fig.1



Fig.2



Fig.3

Check which side you have ordered for the chain to be on. The chain end bracket looks like Fig.1 & 3

Place the chain end bracket in position & mark the screwhole positions with a pencil.

Repeat for the other end, making sure that both brackets are the same distance from the front edge of the window frame.

Remove the brackets & drill a hole at each pencil mark. Screw brackets in position.

Pick up the blind & insert the chain winder end into the chain end bracket Fig.4, making sure the part covering the chain is at the top.



Fig 4



Fig.5

Hold the other end of the blind in position in the bracket and rotate the plastic end until the metal pin pops out as in Fig.5

Your blind should now be in position. Pull the blind down fully and back up fully a couple of times to ensure that the blind is running smoothly.