

How to Measure Roller Blinds



EasyBlinds

DIY
Measure & Install!
Save on the cost of your
custom blinds.

If you would like further advice on your actual window, please email a clear digital image to (info@easyblinds.co.nz). Ensure all curtains are moved away from the window and that handles and the full window is in the photo.



Important Notes:

It is important that measurements are exact.

Always use a steel tape measure, making sure it is straight & tight

Measure blinds in millimetres.

Do not make any deductions for brackets. We will do this for you.

Measure each window individually even if they look the same. There can be small differences.

Inside Mount



Figure 1

To mount your blinds inside the frame, the recess will need to be at least 60mm deep. If it is less please notify us for advice.

Also ensure there are no other parts of the window, or handles etc which will obstruct the operation of your blinds.

Measure the exact width for the blinds in millimeters across the top of the frame where the blind will be mounted.

Measure the exact drop height in millimeters on one side.

See figure 1

Generally Inside Mounted Blinds are front rolled in order to give clearance to handles etc.

Outside Mount

Measure the width for blinds from one side to the other, near the top of the architrave in the position where the blind will be mounted.

Measure the length for blinds from the top of the architrave to the sill, or floor if your window extends to the floor.

See figure 2.

If your architrave is very narrow, you may want the blind to extend past the architrave. Please ask us for additional information in that case.

If you are mounting the blind in some other manner please **DO NOT** supply the fabric width. You will need to discuss this with us or your blind may end up too small.



Figure 2